



IF you can WALK you can RIDE!

TootScoot

Congratulations on your purchase of a TootScoot. These instructions will show you how to assemble your new TootScoot and will help you understand the care and maintenance as well. Please read and follow all of the instructions carefully before you begin. If you have questions please visit us online at www.tootscoot.com

Getting Started

Open the box and remove the bike. Inspect the product and all accessories to ensure everything is there. It is recommended that all threads and bearings be lubricated prior to installation. Do not discard packing materials until the bike is fully assembled. Assemble the bike according to the steps on the following pages.

The TootScoot may not be visible to others, therefore make sure you are aware of your surroundings before you ride. Because the TootScoot does not have reflectors nor brakes it may not meet all bicycle laws and qualifications. Please review your local bicycle laws and regulations before riding. The TootScoot is considered a sidewalk bike and should not be ridden on streets or anywhere there will be traffic from other vehicles.

Remember safety first! Riders should always wear a helmet and protective gear to protect from a fall. The TootScoot should only be ridden under adult supervision to ensure safety. The TootScoot is designed for children ages 2 to 5.

TootScoot is a registered trademark of Buckale, LLC. Buckale, LLC and any of its affiliates take no responsibility for injury and or death by the misuse of the TootScoot or any other products. Please read carefully and abide by all safety instructions. For a detailed list of instructions and uses for the TootScoot, please visit www.tootscoot.com

USER'S MANUAL

Safety: Children should always wear helmets and shoes when using this toy. Children should always use this toy under an adult's supervision. Since the TootScoot doesn't have pedals, children use their feet to brake and stop. Please ensure your child understands how to slow down and stop before riding on their own.

Ensure all hardware is secure and tight before each use.

Ensure the area where your child will be riding is safe and free of obstructions. Balance bikes are intended for flat, level surfaces free of debris, ice, sand, gravel, and water.

If the bike or any of its parts becomes damaged, discontinue use until the damaged part(s) are replaced or properly repaired.

This is a child's toy. Maximum suggested weight: 80 lbs.

Liability: TootScoot Bikes is not responsible for unsafe operation of this ride-on toy, injuries incurred while using this ride-on toy, or any non-compliance of this User's Manual. As with any physical exercise, bike riding can be a hazardous activity. Use at your own risk.

Assembly Instructions:

Suggested assembly tools (not supplied): 15mm socket or open-ended wrench, or adjustable wrench.

PLEASE NOTE: Some of these steps may have been completed in the factory. However, please go through all steps and check pre-assembled parts to ensure precise assembly.

1. Open carton. Remove all contents and packaging from box. Ensure all parts are included using the above parts list. If any parts are missing, STOP.
2. Place bike frame upright on a flat, level surface.
3. Insert saddle assembly into seat post at desired height. You may want to add a little grease to the saddle post to make adjusting the seat height easier in the future. Tighten seat at desired height with the Allen wrench provided. **See photo 11 below.**



4. Determine the center of your handlebars. Remember, they should be facing up like a "Y" when fully assembled. Using the Allen wrench provided, loosen up the top portion of the adjustable bar and place the handlebars into the grooved portion. Fully tighten both screws into place with the Allen wrench. **See photo 5/6/7 above.**
5. Remove protective plastic cap from the bottom of the handlebar assembly. (Make sure the ridged locking nut does not get stuck inside the protective plastic cap!) Insert handlebars with pre-assembled adjustable locking feature into the front frame/fork assembly to the desired height. As with the seat, you may want to add some grease to the ridged locking nut so it is easier to adjust the handlebar height in the future. Using the 6mm Allen wrench provided, tighten the handlebars into place. (Remember to readjust handlebars and seat height in the future as child grows.) **See photo 8/9 below.**
6. Turn frame upside down so it rests on the seat and handlebars.
7. Locate front wheel assembly. Remove and discard the protective plastic covers. Put axle thru front fork and wheel.

8. Ensure the wheel axle is equal length on both sides of the wheel. Adjust if necessary. Place nut on either side of front fork so they rest securely against the outside of fork. Using mini-wrench provided, tighten the outer cap nut on each side to hold the wheel in place. See photo 2/3 below.



REMEMBER: Children learn balance at their own pace. Most children begin by straddling the bike and just walking. Within a few weeks as they are encouraged and become more comfortable, they will begin sitting on the seat and will move a little faster. Soon they will learn to run with the bike and even lift their feet for short distances. Have fun!!

